



SIZING CHART

Arc Clothing and Kits

	S	M	L	XL	2XL	3XL	4XL	5XL	6XL
A	36-38	40-42	44-45	48-50	52-54	56-58	60-62	64-66	68-70
B	32-34	36-38	40-42	44-46	48-50	52-54	56-58	60-62	64-66
C	34.5	35.5	36.5	37.5	39	40.5	42	43.5	45
D	23	23.5	24	25	26	27	28	28	28
E	32	32	32	32	32	32	32	32	32

Measurements are in inches. This chart should be used as a measuring guide only. Garments will vary according to style and fit of the garment.

How to Measure:

CHEST (A): Standing naturally, measure around the fullest part of the chest and shoulder, under the arms with your arms at resting position.

WAIST (B): Measure over undergarments at the natural waistline (usually approx. 0.4in below the navel).

SLEEVE (C) Measure starting from the nape of the neck, over the top of the shoulder, and down the arm until you reach the wrist bone.

PANT BOTTOM (D) Lay the garment flat and measure the width of the pant leg's opening from one side to the other, at the bottom of the pant. Double this number to get the full measurement of the leg opening.

INSEAM (E): Measure from crotch to floor, with shoes.

