



Eddie Bauer® Woodland Shirt Jac EB228

PRODUCT MEASUREMENTS

	2XL	XS	3XL	4XL	L	M	S	XL
Body Length at Back	34	29	34 1/2	35	32	31	30	33
Chest Width	27 1/2	20	29 1/2	31 1/2	24 1/2	23	21 1/2	26
Sleeve Length from Center Back	38 1/2	34 3/4	39 1/4	40	37	36 1/4	35 1/2	37 3/4
Shirt Pocket Height	9 3/4	7 7/8	10 1/4	10 3/4	9	8 5/8	8 1/4	9 3/8
Shirt Pocket Width	7	6 1/2	7	7	7	7	6 1/2	7

BODY LENGTH AT BACK

Measured from high point shoulder to finished hem at back.

CHEST WIDTH

Measured across the chest one inch below armhole when laid flat.

SLEEVE LENGTH FROM CENTER BACK

Measure From CB Neck to Shoulder Point to Finished Sleeve Hem.

SHIRT POCKET HEIGHT

Measure from top to bottom at center.

SHIRT POCKET WIDTH

Measure from side to side at top edge.