



Safety Jackets Sizing Chart

Choosing the correct size in safety apparel is crucial for optimal protection and performance.

For an accurate size and fit in Global Glove safety jackets, please refer to the following general sizing dimensions.

BOMBERS

GLO-EB1 • GLO-EB4 • GLO-B2

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH
MEDIUM	28.75	26.75	25.5
LARGE	29.5	28	26
XL	30.25	29.25	26.5
XLT	33.5	29.25	28.5
2XL	31	30	27.25
2XLT	34.25	30	29.25
3XL	32	30.75	27.75
4XL	32.75	31.5	28.25
5XL	33.5	32.25	28.5

WINDBREAKER

GLO-WB1

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH
MEDIUM	28.5	24	26
LARGE	29.25	26	26.5
XL	30.25	28	27
2XL	31.25	30	27
3XL	32.25	32	27.5
6XL	32.25	38	27.5

SOFTSHELL

GLO-SJ1

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH
MEDIUM	28.5	24	26
LARGE	29.25	26	26.5
XL	30.25	28	27
2XL	31.25	30	27
3XL	31.25	32	27.5
4XL	32.25	34	27.5
5XL	32.25	36	27.5



SOFTSHELL

EV-SJ1

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH
SMALL	29	22.5	25.5
MEDIUM	29	24	26
LARGE	30	26	26.5
XL	31	28	27
XLT	34	28	29
2XL	32	30	27
2XLT	35	30	29
3XL	32	32	27.5
4XL	33	34	28

ALL MEASUREMENTS IN INCHES

Estimate size to the closest fit. Body proportions may vary.